



HOCH™ gen2 2.0 speakers

QUICK GUIDE
GUÍA RÁPIDA DE USO

_01 SWITCH ON

Connect the active speaker to the mains through the respective power cable [K]. Connect the two speakers together with the bipolar cable [L]. Press the POWER switch [A] on the back panel to turn on the speaker.

_02 CONNECTION BETWEEN THE UNIT AND THE AUDIO SOURCE

_A BLUETOOTH® MODE


Turn on the speaker and press the MODE key [E] to switch to **Bluetooth® mode**. The blue LED should light up and blink. Start the Bluetooth® search with the device to be paired (Mobile, PC, TV, Notebook, Tablet, etc.). Select “HOCH” in your device. The **blue** LED will be solid once the link is established.

_B LOW-LEVEL RCA CONNECTION

Turn on the speaker and press the MODE key [E] to switch to **RCA mode**. Connect the **RCA** cable [J] to the INPUT socket, and connect the 3,5 mm Mini plug to the output of your reproducing device.


_C OPTICAL CONNECTION (cable not included)

Turn on the speaker and press the MODE key [E] to switch to **OPTICAL mode**. Connect the Optical cable to the OPTICAL socket [D], and connect the other end of the cable to the output of your reproducing device.




_03 BACK PANEL


- A_ POWER SWITCH: On / Off
 B_ AC IN
 C_ RCA INPUT
 D_ OPTICAL INPUT
 E_ SPEAKER OUTPUT

**_04 SIDE CONTROL PANEL**

- E_ PAIRING / MODE (TREBBLE - BASS)
 F_ STAND BY / INPUT
 G_ VOLUME UP / EQ +
 H_ VOLUME DOWN / EQ -
 I_ INPUT INDICATOR LED
 J_ EQ INDICATOR LED

**_05 CABLES**

- J_ RCA to 3.5 mini plug stereo cable
 K_ Power cable
 L_ Bipolar cable



_01 ENCENDIDO

Conecte el parlante activo a la red de corriente eléctrica con el cable correspondiente [K]. Conecte los dos parlantes entre si con el cable bipolar [L]. Encienda el equipo con la tecla [A] que está en el panel trasero.

_02 CONEXIÓN ENTRE HOCH Y LA FUENTE DE AUDIO

_A MODO BLUETOOTH®


Encienda el parlante y presione la tecla MODE [E] para cambiar al modo **Bluetooth®**. El LED azul debe encenderse y parpadear. Inicie la búsqueda de Bluetooth® con el dispositivo a vincular (Móvil, PC, TV, Notebook, Tablet, etc.) Seleccione "HOCH" en su dispositivo. El LED azul permanecerá fijo una vez que se establezca el enlace.

_B CONEXIÓN RCA

Encienda el parlante y presione la tecla MODE [E] para cambiar al modo **RCA**. Conecte el cable RCA [E] a la entrada [C] y luego conecte la ficha 3,5 mm Mini plug a la salida de audio de su dispositivo reproductor.


_C CONEXIÓN OPTICA (cable no incluido)

Encienda el parlante y presione la tecla MODE [E] para cambiar al modo **Óptico**. Conecte el cable óptico al terminal [D] y conecte el otro extremo del cable a la salida de audio de su dispositivo reproductor




_03 PANEL TRASERO


- A_ TECLA DE ENCENDIDO
 B_ CONEXIÓN A RED ELÉCTRICA
 C_ ENTRADA RCA
 D_ ENTRADA ÓPTICA
 E_ CONEXION PARA PARLANTE PASIVO

**_04 PANEL LATERAL**

- E_ PAIRING / MODE (TREBBLE - BASS)
 F_ STAND BY / INPUT
 G_ VOLUME UP / EQ +
 H_ VOLUME DOWN / EQ -
 I_ INPUT INDICATOR LED
 J_ EQ INDICATOR LED

**_05 CABLES**

- J_ RCA A 3,5 Mini plug Cable Stereo
 K_ Cable de alimentación
 L_ Cable bipolar





Thonet & Vander Germany GmbH. All rights reserved. Thonet & Vander®, Deutsche Designtechnik and related trademarks, names and logos are the property of Thonet & Vander Germany GmbH and are registered and/or used in Germany and countries around the world. Other brands and trade names mentioned belong to their respective owners.

Thonet & Vander Germany GmbH. Todos los derechos reservados. Thonet & Vander®, Deutsche Designtechnik y las marcas comerciales, nombres y logotipos relacionados son propiedad de Thonet & Vander Germany GmbH y están registrados y/o utilizados en Alemania y países de todo el mundo. Otras marcas y nombres comerciales mencionados pertenecen a sus respectivos propietarios.



GERMAN
ENGINEERING
& DESIGN



GREEN
SOUND

Thonet & Vander Germany GmbH
Königstorgraben 11, (90402) Nürnberg, Germany.
© All rights reserved
info@thonet-vander.com | www.thonet-vander.com