




VERTRAG™

2.0 speakers

QUICK GUIDE
GUÍA RÁPIDA DE USO

_01 SYSTEM INSTALLATION




_02 BLUETOOTH® PAIRING

Switch on the speaker. A blue light will start blinking, this means the speaker is in **pairing mode**. Turn on Bluetooth® on your device (smartphone, tablet, PC, etc.) and select **VER-TRAG BT™** to pair the speaker. The light will stop blinking once the connection is established. If pairing fails, try again. If you require further support, please send an e-mail to support@thonet-vander.com. For switching from any other mode to Bluetooth® mode, press the BT button [5] on your remote control or go to the Speaker Side Panel and press the Volume button [B] for 2 seconds.

_03 VOLUME CONTROL | From Side Panel

- A_ Mode LED on
- B_ Digital Volume Control / Mode button (Switch Bluetooth®, Optical, Aux mode by pressing this button for 2 seconds)
- C_ Adjust treble or high frequencies
- D_ Adjust bass or low frequencies




_04 REMOTE CONTROL

REMOTE CONTROL

- 1_ Stand by mode
- 2_ Mute
- 3_ Bluetooth® pairing mode (hold press)
- 4_ Optical input
- 5_ Bluetooth® input
- 6_ Auxiliary RCA /Jack 3.5 mm input
- 7_ Increase Volume
- 8_ Decrease Volume

LED ACTION [A] on Side Panel

- 1_ Steady red light
- 2_ Blinking red, green or blue light
- 3_ Blue light blinking
- 4_ Steady green light
- 5_ Steady blue light
- 6_ Steady green light



_04 ACCESORIES | Our VERTRAG BT™ 2.0 speakers include:

- _ Remote Control
- _ RCA Stereo to 3.5 mm Stereo Auxiliary Cable
- _ Transparent cable for connecting passive speaker
- _ Power cable (plug IEC 60320 C7)* or power cable with ground tab (plug IEC 60320 C7)* or UK (plug BS 1363)*
- (*) according to country

_01 INSTALACIÓN DEL SISTEMA

A.



B.



C.


ROJO



BLANCO



Cable RCA Estéreo a RCA Estéreo
(no incluido)




ROJO



BLANCO




Cable RCA Estéreo a Auxiliar
Estéreo 3.5 mm (incluido)



D.




Cable Óptico (no incluido)







E.



Cable de Alimentación (incluido)



F.




_02 EMPAREJAMIENTO BLUETOOTH®

Encender el parlante. Una luz azul comenzará a parpadear, esto significa que el altavoz está en **modo de emparejamiento**. Activar Bluetooth® en el dispositivo (smartphone, tablet, PC, etc.) y

seleccionar **VERTRAG BT™** para iniciar conexión. La luz dejará de parpadear una vez establecida la conexión. Si la conexión falla, intente de nuevo. Si requiere mayor soporte, envíe un e-mail a support@thonet-vander.com. Para cambiar de cualquier otro modo al modo Bluetooth®, presione el botón BT [5] en su control remoto o vaya al Panel Lateral del parlante y presione el botón de volumen [B] durante 2 segundos.

_03 CONTROL DE VOLUMEN | Desde el Panel Lateral

- A_ Led de indicación de modo encendido
- B_ Control de volumen digital / Botón cambio de modo (Bluetooth®, Óptico, Auxiliar; manteniendo presionado 2 segundos)
- C_ Ajuste de agudos o frecuencias altas
- D_ Ajuste de graves o frecuencias bajas




_04 CONTROL REMOTO

CONTROL REMOTO

- 1_ Stand by / Descanso
- 2_ Mute / Silencio
- 3_ Emparejamiento BT® (mantener presionado)
- 4_ Entrada Óptica
- 5_ Entrada Bluetooth®
- 6_ Entrada Auxiliar RCA / Jack 3.5 mm
- 7_ Subir Volumen
- 8_ Bajar Volumen

ACCIÓN DEL LED [A] en el Panel Lateral

- 1_ Luz roja permanente
- 2_ Luz roja, verde o azul parpadeando lentamente
- 3_ Luz azul parpadeando
- 4_ Luz verde permanente
- 5_ Luz azul permanente
- 6_ Luz verde permanente



_04 ACCESORIOS | Nuestro VERTRAG BT™ 2.0 speakers incluyen:

- _ Control Remoto
- _ Cable RCA Estéreo a Auxiliar Estéreo 3.5 mm
- _ Cable transparente para conexión de altavoz pasivo
- _ Cable de Alimentación (conector IEC 60320 C7)* o Cable de Alimentación



Thonet & Vander Germany GmbH. All rights reserved. Thonet & Vander®, Deutsche Designtechnik and related trademarks, names and logos are the property of Thonet & Vander Germany GmbH and are registered and/or used in Germany and countries around the world. Other brands and trade names mentioned belong to their respective owners.

Thonet & Vander Germany GmbH. Todos los derechos reservados. Thonet & Vander®, Deutsche Designtechnik y las marcas comerciales, nombres y logotipos relacionados son propiedad de Thonet & Vander Germany GmbH y están registrados y/o utilizados en Alemania y países de todo el mundo. Otras marcas y nombres comerciales mencionados pertenecen a sus respectivos propietarios.



GERMAN
ENGINEERING
& DESIGN



GREEN
SOUND

Thonet & Vander Germany GmbH

Königstorgraben 11, (90402) Nürnberg, Germany.

© All rights reserved

info@thonet-vander.com | www.thonet-vander.com