



VR10™

neckband

QUICK GUIDE
GUÍA RÁPIDA DE USO

_01 CONTENTS

- A_** Bluetooth® Earphone
- B_** USB-C charging cable
- C_** Quick Guide

_02 CONTROL

- 1_** Power ON/Power OFF
 - Answer call: short press
 - Dial Back: double short press
 - Google/Siri Voice Assistant: three short press
- 2_** Volume up: long press / Next song: short press
- 3_** Volume down: long press / Last song: short press

_03 BLUETOOTH® PAIRING

- A_** Power ON: long press [1] button for more than 3 seconds, the headphone is no turned ON, enter the Bluetooth® mode. The blue and red light will flash alternately.
- B_** Power OFF: long press [1] button for more than 3 seconds, the neckband will be turned OFF, the LED lights will be off.

_04 PAIRING NAME: T&V R10**_05 FUNCTION: Bluetooth® (call)****_06 POWER ON STATUS: Auto power-off after disconnected for 5 min****_07 LED ACTION**

- A_ CHARGING:** red LED light is on, it will be power off once full charged.
- B_ POWER ON:** blue LED light is on.
- C_ POWER OFF:** red LED light is on.
- D_ PAIRING:** blue and red LED light flashes alternately.
- E_ CONNECTED:** blue LED light flashes slowly.
- F_ WORK:** blue LED light flashes slowly.

_08 SPECIFICATIONS

- Bluetooth® version:** 5.0
- Speaker size:** 10 mm
- Impedance:** 160hm
- Sensitivity:** 92± 3db
- Freq. Response:** 20-20,000 Hz
- Battery Voltage:** 3.7±0.5V
- Playing time:** 7 hours
- Charging time:** 2 hours
- Working range:** 10 meters
- Max. power:** 5mW

_01 CONTENIDO

- A_ Auricular Bluetooth®
- B_ Cable de carga USB-C
- C_ Guía rápida de uso

_02 CONTROL

- 1_ Encendido/Apagado
 - Responder llamado: presione una vez
 - Marcar atrás: presionar dos veces
 - Asistente de voz Google/Siri: presione tres veces
- 2_ Subir volumen: mantener presionado
 - Próxima canción: presionar una vez
- 3_ Bajar volumen: mantener presionado
 - Canción anterior: presionar una vez

_03 EMPAREJAMIENTO BLUETOOTH®

- A_ Encendido: mantener presionado [1] por más de 3 segundos, el auricular se encenderá y entrará en modo Bluetooth®. La luz alternará entre rojo y azul.
- B_ Apagado: Mantener presionado [1] por más de 3 segundos, el auricular se apagará. La luz se apagará.

_04 NOMBRE DE EMPAREJAMIENTO: T&V R10

_05 FUNCIÓN: Bluetooth® (llamadas)

_06 ESTADO DE ENCENDIDO: Auto apagado después de estar desconectado por 5 minutos

_07 ACCIÓN DEL LED

- A_ CARGANDO: se enciende el LED rojo. Se apaga cuando esté 100% cargado.
- B_ ENCENDIDO: el LED azul está encendido.
- C_ APAGADO: el LED rojo titilará y luego se apagará.
- D_ EMPAREJADO: el LED alternará entre rojo y azul.
- E_ CONECTADO: el LED titilará en azul lentamente.
- F_ FUNCIONANDO: el LED titilará en azul lentamente.

_08 ESPECIFICACIONES

Versión Bluetooth®: 5.0

Tamaño driver: 10 mm

Impedancia: 160hm

Sensibilidad: 92± 3db

Frec. de respuesta: 20-20,000 Hz

Voltaje batería: 3.7±0.5V

Tiempo de uso: 7 horas

Tiempo de carga: 2 horas

Alcance: 10 metros

Potencia máxima: 5mW

Capacidad batería: 70 MAh



Thonet & Vander Germany GmbH. All rights reserved. Thonet & Vander®, Deutsche Designtechnik and related trademarks, names and logos are the property of Thonet & Vander Germany GmbH and are registered and/or used in Germany and countries around the world. Other brands and trade names mentioned belong to their respective owners.

Thonet & Vander Germany GmbH. Todos los derechos reservados. Thonet & Vander®, Deutsche Designtechnik y las marcas comerciales, nombres y logotipos relacionados son propiedad de Thonet & Vander Germany GmbH y están registrados y/o utilizados en Alemania y países de todo el mundo. Otras marcas y nombres comerciales mencionados pertenecen a sus respectivos propietarios.



GERMAN
ENGINEERING
& DESIGN



GREEN
SOUND

Thonet & Vander Germany GmbH

Königstorggraben 11, (90402) Nürnberg, Germany.

© All rights reserved

info@thonet-vander.com | www.thonet-vander.com